

"Continuous tone" closure for T25-35.

Bend pin 1 out, jumper to pin 24.

Bend pin 23 out, jumper to pin 12. ALL ON U7

